

When taking a reading, hold DipCell comparator so that you are looking above the horizon with sunlight coming over your shoulder.

Free Chlorine Cl₂	1 Fill DipCell to the fill line with sample. 2 Add 5 drops of DPD 1A and 5 drops of *DPD 1B. Cap and invert to mix. 3 Match sample color to a color standard. Record result as ppm Free Chlorine.
--	---

Total Chlorine Cl₂	1 Remove cap and add 5 drops of *DPD 3. 2 Cap and invert to mix. 3 Match sample color to a color standard. Record result as ppm Total Chlorine. NOTE: Total Chlorine - Free Chlorine = Combined Chlorine
---	--

pH	1 If DipCell is empty, fill to line with sample. 2 Add 5 drops of *pH indicator. Cap and invert to mix. 3 Match sample color to a color standard. Record as pH. If pH is not within desired range, retain sample for Acid/Base Demand test.
-----------	---

Acid Base	1 Remove cap from DipCell. 2 If pH is HIGH: Add *Acid, one drop at a time, and mix until color matches desired pH. See chart for dosage recommendation. 3 If pH is LOW: Add Base, one drop at a time, and mix until color matches desired pH. See chart for dosage recommendation.
------------------	--

Total Alkalinity Alk	1 Fill tube (0929) to the upper X10 line with sample. 2 Add 5 drops of *Alk 1. Swirl to mix. 3 Add *Alk Titrant dropwise while swirling until color changes from blue-green to RED. Record total drops. 4 Each drop equals 10 ppm Total Alkalinity. Note: for HIGH range tests: Fill to X20 line in Step 1. Each drop = 20 ppm Alkalinity.
--------------------------------	---

Calcium Hardness Hard	1 Fill tube (0929) to the lower X20 line with sample. 2 Add 5 drops of *Hard 1 and 5 drops of *Hard 2. Swirl to mix. 3 Add Hard Titrant dropwise while swirling until color changes from red through purple to BLUE. Record total drops. 4 Each drop equals 20 ppm Ca Hardness. Note: for LOW range tests: Fill to X10 line in Step 1. Each drop = 10 ppm Calcium Hardness
---------------------------------	---

Cyanuric Acid CYA	1 Remove square tube and cap from round tube. Fill round tube to top line with sample. 2 Add one *CYA tablet. Crush tablet with tablet crusher. Mix until disintegrated. 3 Insert square tube into round tube. 4 Viewing from above, adjust the square tube until the black dot just barely disappears. Read result in ppm CYA at water level WITHIN SQUARE TUBE. Note: To read above 100 ppm retest by adding sample to lower line, add tap water to top line. Multiply result by 2.
-----------------------------	--

*Hazardous materials: Read MSDS and product label before use.

LaMotte Company • Chestertown • Maryland • 21620

7013 • DL-51 • 3/02

